Getting Started with your DVR

5. Deleting a Scheduled Timer (Future Recording)

a. If you want to delete a scheduled recording or timer, press the DVR button on your DISH remote.





The "DVR" screen appears.

b. The "My Recordings" tab is highlighted. Press the SELECT button to look at the "My Recording" options.





The "Media Options" drop down menu appears.

c. Select "Timers" from the drop down menu.



The "Timers" screen appears.

d. Scroll down until the timer you would like to delete is highlighted and then press SELECT.





A drop down menu appears.

e. Scroll down and select "Delete Timer."



A warning message appears.

f. Select "Yes."



The "Timers" screen appears and the deleted schedule/timer will be gone.

1. Using Your DVR While Watching Live TV

Pause TV

a. If you are interrupted while watching TV, press PAUSE on your DISH remote.





The program pauses for up to 1 hour.

Resume watching

b. When you would like to resume watching TV, press PLAY.





The program resumes.

Skip back (10 seconds)

c. If you missed something and want to see it again, press SKIP BACK to go backward 10 seconds at a time.





The program skips back 10 seconds at a time.

Skip forward (30 seconds)

d. Press SKIP FWD to go forward 30 seconds at a time.





The program skips forward 30 seconds at a time, until you reach live TV.

View live TV

e. If you want to view live TV, press VIEW LIVE TV.





The program goes to live TV.

PN 193541

2. Recording a TV program

Record a program NOW

a. If you are watching TV and want to begin recording that program, press RECORD on your DISH remote.





The "REC" logo appears and recording will begin. Press RECORD again to adjust end time.

Record a program in the FUTURE

a. If you want to schedule a recording for a program that takes place in the future, press GUIDE.





The Program Guide appears.

b. Scroll through the Guide until the program that you want to record is highlighted and then press SELECT.





A drop down menu appears.

c. Select "Record This" to instantly record this show once with default options.

OR

Select "Record Series Timer" to bring up the "Event Timer" screen.



The "Event Timer" screen appears.

d. Scroll through "Episodes" and select the frequency you would like to use to record the program and then select "Create."



The attention screen appears. Then the Program Guide will appear with a record icon next to the program.

FREQUENCY

New and Reruns	Record all episodes.
Only New	Records only new episodes.
Once	Records the show only one time.

3. Watching a Recording

a. If you would like to view a program that you previously recorded, press the DVR button on your DISH remote.





The "DVR" screen appears.

b. Scroll through until the program you would like to watch is highlighted, and press SELECT.



A menu appears above the DVR event.

c. Select "Start Over" to play your recording from the beginning.

OR

Press the PLAY button to resume watching.

4. Deleting a Recorded Program

a. If you want to delete a recorded program, press the DVR button on your DISH remote





The "DVR" screen appears.

b. Scroll through until the program you would like to delete is highlighted and then press SELECT.





A menu appears above the event.

c. Scroll up and select "Delete."



A warning message appears.

d. Select "Yes."



A confirmation message appears.