
LET'S JUMP RIGHT IN



Hopper™

dish®



THE SMARTEST ANIMAL IN THE ENTERTAINMENT KINGDOM.



dish


Hopper™

TRAINED TO GIVE YOU THE BEST IN WHOLE-HOME ENTERTAINMENT.

Welcome to the Hopper, a Whole-Home HD DVR from DISH that brings full DVR functionality, including pausing live TV, to every TV in your house. And with dozens of features you'll love, it won't take long to see why the Hopper will be a great addition to your family. This guide will introduce you to everything the Hopper can do to make your entertainment experience the best you can get.









THE HOPPER AND JOEY. TOGETHER THEY CREATE WHOLE-HOME DVR ENTERTAINMENT OF EPIC PROPORTIONS.

THE HOPPER



The Hopper is the hub for all things entertainment. It's a three-tuner Whole-Home HD DVR that lets you watch or record up to three live HD channels at once and play them back from any room in your home. Plus, you can record up to six HD channels at once with PrimeTime Anytime™.[1] It's one HD DVR that serves four different TVs at the same time, so everyone can be in different rooms watching their own shows.

THE JOEY



The Joey connects to other TVs in your home and links with the Hopper to create a Whole-Home DVR network. It offers all the features of the Hopper.[2] You can connect a Joey to a high-definition or standard-definition TV. And thanks to its compact size, it easily tucks away behind your TV.

[1] Restrictions apply. [2] Excludes Picture-in-picture.

PRESENTING THE FEATURES THAT WILL CHANGE THE WAY YOU WATCH TV FOREVER.



WHOLE-HOME DVR

- Watch, pause, record and rewind live TV on any TV in your house.
- Record up to 3 shows at the same time from any TV.[1]
- Access your DVR library from any room.
- Start watching in one room, pause and continue in any other room with a Joey.
- Record over 250 hours of HD programming.

PRIMETIME ANYTIME™

- Set the PrimeTime Anytime feature once and watch primetime shows from ABC, CBS, FOX and NBC in HD for 8 days after they've aired.
- Record up to six HD shows at once during primetime and play them back in any room.



TV EVERYWHERE™

- The same TV you watch at home is now available on the go.
- Connect a Sling Adapter® to the Hopper and enjoy all your channels and everything on your DVR on your computer or mobile device.

ON DEMAND™

- Enjoy the hits in 1080p resolution – 28 days before Netflix® or Redbox®.
- Access thousands of movies and TV shows including Blockbuster @Home™ titles right on your Hopper.



MUSIC

- First and only pay-TV provider to feature SiriusXM satellite music channels.
- Enjoy commerical-free music in every room of the house.

SiriusXM™ SATELLITE RADIO

APPS & MORE

- Do more on your TV with entertainment, sports and news apps.
- Take your TV to the next level with high-definition 3D Video On Demand.



[1] TVs connected to a Hopper, which has 3 satellite tuners, allowing you to record up to 3 shows at one time. [2] The PrimeTime Anytime feature records 4 local HD channels with one tuner; with the second and third tuner you can record 2 additional channels. Feature only available with ABC, CBS, FOX and NBC broadcast in HD. Some markets may not offer all four networks in HD.
* Pandora and Facebook Apps are coming soon.

START IN ONE ROOM. FINISH IN ANOTHER. ENJOY THOROUGHLY IN BETWEEN.

You're always in more than one place in your home. Fortunately, so is Hopper. With its Whole-Home DVR network, Hopper makes it easier than ever to start watching a program in one room and resume in another.

1. Press the Pause button on your remote to pause the program.
2. Go to the next room and pick up the DISH remote.
3. Press the red button to display the TV Viewing Status screen.
4. Select the program you want to resume and it will continue from where you paused it.



FIND WHAT YOU WANT, FAST. HOPPER FAST.

Predictive Search makes it easier than ever to locate programs saved on your Hopper or find what you're looking for on live TV.

1. Press the Search button on your remote or press the Menu button and select the Search tile.
2. Using the on-screen keyboard, enter a title, actor or keyword.
3. Your Hopper and Joey will begin displaying results as soon as you start typing.




STUNNING GRAPHICAL INTERFACE IN HD

Browse your Program Guide, DVR, and TV viewing options using familiar network logos. Explore your favorite programming and view search results in an easy-to-read graphical layout.



» TIP: USE THE COLOR KEYS ON YOUR REMOTE TO NAVIGATE THE GUIDE & DVR.



STORE OVER 250 HD HOURS OF LAUGHS, TOUCHDOWNS & EXPLOSIONS.

Thanks to its 2 TB hard drive, the Hopper features the most storage of any DVR in the pay-TV industry. 2 TB is code-speak for hundreds of On Demand movies and shows plus the ability to record and store over 250 hours of your favorite shows, movies and more—all in HD. And if that's not enough, you can easily connect an external hard drive to your Hopper and never worry about deleting another movie or episode again.



To access your recorded content, press the DVR button and select the program you want to watch.

LOCATE LOST REMOTES BEFORE YOU CAN SAY 'WHERE'S THE REMOTE?'

Your remote does more than change channels, turn up the volume and pause live TV. It also can locate itself whenever it's lost.

1. Press the Locate Remote button on the front of your Hopper or Joey unit.
2. The remote will beep to help you locate it.
3. After locating the remote, hold the Select button until the beeping stops.



Finding your remote is as easy as pressing this button.

And because the Hopper remote uses the latest in remote technology, you can place your Hopper or Joey inside your TV stand or behind your TV without worrying whether you'll be able to change the channel.

KEEP UP WITH YOUR FAVORITE SHOWS WITH PRIMETIME ANYTIME.

PRIME TIME ANYTIME

Only the Hopper has PrimeTime Anytime[1], the feature that gives you instant On Demand access to your favorite shows on ABC, CBS, FOX and NBC in crystal-clear HD. Programs airing during primetime hours (Mon-Sat, 8-11pm EST/Sun, 7-11pm EST) can be accessed for up to 8 days from their initial airdate, and you can always save your shows to your DVR library to watch anytime.

» RECORD 6 SHOWS DURING PRIMETIME HOURS: ABC, CBS, FOX AND NBC. PLUS, 2 ADDITIONAL CHANNELS OF YOUR CHOOSING.





[1] PrimeTime Anytime is only available with local channels broadcast in HD, which may not be not available in all markets.


TO ENABLE PRIMETIME ANYTIME, SEE THE DIRECTIONS BELOW.



1. Press the Menu button on your remote and select the PrimeTime Anytime tile.



2. Select the Enable button to turn on the feature and select Save.



3. PrimeTime Anytime will begin recording your HD primetime shows each night.



4. To view your shows, press the DVR button on your remote and select the PrimeTime Anytime folder.

» 8 DAYS OF PRIMETIME ANYTIME MEANS OVER 200 SHOWS TO PICK FROM – YOU'LL NEVER MISS A SHOW AGAIN!

INSTANTLY WATCH YOUR FAVORITE SHOWS AND MOVIES. ALL 20,000 OF THEM.

dish·online

DISH Online is the newest way to watch your favorite programs. Instantly stream over 20,000 free titles on your computer with a broadband Internet connection. As a DISH customer, you can log in to unlock even more content from the networks you subscribe to at home, including HBO, Starz, Epix and more.

DISH Online automatically comes with your service at no additional cost. And even though DISH Online is an Internet service, it also works with your Hopper by letting you search the guide and schedule recordings on your DVR.

1. Simply go to dish.com and click Log In in the upper right-hand corner to register your account and create a username and password.
2. Once you have your username and password, log in to your account at dishonline.com.
3. Browse through thousands of available On Demand titles and select one to watch instantly.









LIVE TV » TO GO

ENTERTAINMENT AS MOBILE AS YOU ARE.

Only DISH allows you to watch the same live and recorded TV you watch at home on the go. All your channels and everything saved on your DVR can be viewed on your computer, smartphone, or tablet. All you need is an Internet connection and the Sling Adapter.

1. Connect your Hopper to broadband Internet.
2. Plug in the Sling Adapter and log in to dishonline.com on your computer or download our free DISH Remote Access mobile app.
3. Enjoy live TV and DVR recordings wherever you go.



Sling® Adapter

BRING THE BIG SCREEN TO YOUR HOME SCREEN.



DISH ON DEMAND

DISH was the first to offer 1080p Video On Demand. Watch your movies with stunning clarity and resolution equal to Blu-ray! Select from thousands of movie titles and watch them as often as you like within a 24-hour period. Plus, get instant access to hundreds of TV shows from many of your favorite channels.

To access On Demand, press the DISH On Demand button on your remote. Press the * button on your remote to see titles available as part of your subscription.[1] You can also view new release 1080p titles available on channel one in the program guide.

BLOCKBUSTER @HOME

DISH has joined with Blockbuster to offer customers the most extensive collection of movies, games, family programs and TV shows available. Your Blockbuster @Home subscription gives you access to thousands of free movies. To view available movie titles, press Menu on your remote and select the Blockbuster @Home tile.[2]

BLOCKBUSTER @HOME™

[1] Some On Demand titles require a rental fee. Other titles are available for free based on your programming subscription, including HBO and EPIX.
[2] Your Hopper must be connected to the Internet to access the full library of titles available.

CONNECT HOPPER TO THE INTERNET

To gain instant access to thousands of On Demand movies and TV shows, connect your Hopper to broadband Internet. Visit mydish.com/connect for more information on how to get connected.



NOT CONNECTED?

Get instant, unlimited access to hundreds of movies and shows without connecting to the Internet. DISH Unplugged is integrated into Hopper and automatically delivers hundreds of On Demand titles including Blockbuster @Home titles to your hard drive–whether you are connected to the Internet or not. To access movies included in your subscription, press the Menu button on your remote and select the Blockbuster @Home tile.* Follow the on-screen instructions to see available titles.

dish unplugged

» QUICKLY FIND EXACTLY WHAT YOU'RE LOOKING FOR WITH EASY-TO-USE ON-SCREEN FILTERS.



* Video library regularly subject to change; movies require time to download to Hopper.

WITH HOPPER, TV IS JUST THE BEGINNING.

Hopper brings you more than the best in TV, movies, music and entertainment. It also brings the best of the Web to your TV with the latest and greatest news, sports, music, weather and game apps. You can even share your favorite shows and movies with friends on Twitter®.

Press the Menu button on your remote and select the Apps tile.






* Pandora and Facebook Apps are coming soon.



LET HOPPER DJ YOUR NEXT PARTY.

Music fans will be happy to know that the Hopper delivers the same SiriusXM Satellite music channels you enjoy in your car right to your TV. We have a feeling you'll be busting a move in no time. Type 99 on your remote followed by the number of your favorite music channel. SiriusXM music channels are available with select programming packages.

((SiriusXM™))
SATELLITE RADIO



TAKE HOPPER TO THE 3RD DIMENSION.

If your TV supports 3D display, you can experience movies like never before right on your Hopper. If your Hopper is connected to broadband Internet, you can rent a wide selection of 3D movies on channels 1 and 501. For more information about 3D Video On Demand, visit mydish.com/3D.

1. Make sure your Hopper is connected to broadband Internet.
2. Type in channel 1 or 501 to access Video On Demand.
3. Or press the MENU button on your remote and select the On Demand tile.
4. Choose a title with a 3D icon.

Requires 3D television.



HOPPER ADJUSTS VOLUME SO YOU DON'T HAVE TO.

SRS TruVolume

You know when a commercial turns on and you scramble to find the remote to turn down the volume? Well, thanks to SRS TruVolume, that will be a thing of the past. SRS TruVolume eliminates volume fluctuations during commercials or when changing channels so you enjoy a more natural listening experience.

MULTI-CHANNEL / RECALL

QUICKLY SWAP BETWEEN THE LAST FOUR CHANNELS YOU VIEWED USING THE RECALL BUTTON ON YOUR REMOTE.

SRS TruVolume not available on all audio outputs/signals.

Inside pocket fold
don't
print



WE'RE ALWAYS HAPPY TO HELP.

Every good study guide comes with a few cheat sheets. That's why this one has a pocket to hold all your reference materials.

- Remote Control Quick Reference Guide
- DVR Basics Quick Reference Guide
- DISH Channel Lineup Guide
- Safety information, Important Product Information, Warranty and Residential Customer Agreement Pack

Should you have questions that this booklet or the enclosed reference guides don't answer, here are some more helpful resources.

- **mydish.com/manuals**
- **mydish.com/chat**
- **mydish.com/support**
- **Type 101 on your remote**
- **1-800-333-DISH (3474)**

dish®

For all your customer needs, go to mydish.com/chat or call the Customer Service Center at 1-800-333-DISH (3474).

Hopper™